



**Pipeline Protection
For the
Long Haul.**





Scapa North America is a leading manufacturer of anticorrosion pipeline protection systems and has provided products that meet the rigorous demands of on-land pipelines for more than 25 years.

Scapa RENWRAP® products are designed for application to new construction pipe in both plant and infield settings, as well as the repair and reconditioning of existing pipelines in the oil, gas, and water industries.

Our efficient, cost-effective products consistently offer excellent adhesion and shear resistance and operate under a wide range of temperatures.

Scapa adhesive systems are impermeable to water and oxygen, and are compatible with coal tar, fusion bond epoxy, asphalt, and polyethylene pipeline coatings. They have sufficient adhesion and strength to resist soil stress, under-film migration of moisture, environmental stress cracking, and mechanical damage during handling.

Line Travel

Scapa North America offers cost-effective products for over-the-ditch line travel applications. The products in this range exhibit aggressive adhesion, operate under a wide range of temperatures, and are resistant to high levels of soil stress. They form an impermeable barrier to water and oxygen and are resistant to environmental stress cracking caused by elevated temperatures. RENWRAP rock-shield products protect coated pipe from the damage that typically occurs during backfilling.

Joint Wrapping

Our joint wrapping products are specifically designed for hand-wrapping field joints, fittings, ells, and tees. They maintain adhesion to plastic and FBE pre-coated pipe under a wide range of temperatures and are able to fill voids around irregular shapes. All products are compatible with coal tar, fusion bond epoxy, asphalt, and polyethylene pipeline coatings and provide excellent protection against electrolytic and environmental corrosion.

Yard Coating

Scapa yard coating products provide excellent adhesion, shear, and low-temperature properties and are resistant to environmental stress cracking. Their tough polyethylene backings provide protection from damage caused by lowering in, backfilling, and soil stress.

COATINGS

RENWRAP Product #	Description	Colors	Total Thickness mils (mm)	Backing Thickness mils (mm)	Adhesive Thickness mils (mm)
300	Low density polyethylene film, calendered with a rubber adhesive.	Black*	10 (0.254) 12 (0.305) 20 (0.508)	7 (0.178) 8 (0.203) 15 (0.381)	3 (0.076) 4 (0.102) 5 (0.127)
308**	Machine applied high/low density polyethylene film, calendered with a butyl rubber adhesive.	Black	15 (0.381) 18 (0.457) 20 (0.508) 25 (0.635)	9 (0.229) 10 (0.254) 12 (0.305) 13 (0.330)	6 (0.152) 8 (0.203) 8 (0.203) 12 (0.305)
308 HS**	Machine applied high/low density polyethylene film, calendered with a cross-linked butyl rubber adhesive.	Black	15 (0.381) 20 (0.508)	9 (0.229) 12 (0.305)	6 (0.152) 8 (0.203)
309 HT/HS**	Machine applied ESCR polyethylene film, calendered with a cross-linked butyl rubber adhesive. The product must be used with RENWRAP HT/HS primer.	Black	20 (0.508)	12 (0.305)	8 (0.203)
330	Low density polyethylene film, calendered with a butyl rubber adhesive.	Black, White & Light Blue	25 (0.635) 30 (0.762) 35 (0.889) 50 (1.270)	7 (0.178) 7 (0.178) 7 (0.178) 10 (0.254)	18 (0.457) 23 (0.584) 28 (0.711) 40 (1.016)
330L	Low density polyethylene film, calendered with a butyl rubber adhesive. The product is supplied with a release liner to facilitate roll unwinding.	Black, White, Gray & Light Blue	25 (0.635) 35 (0.889) 50 (1.270)	7 (0.178) 7 (0.178) 10 (0.254)	18 (0.457) 28 (0.711) 40 (1.016)
331	Butyl rubber adhesive.	Black	35 (0.889)	–	–
350	Perforated polyethylene film for cathodic protection purposes.	Black*	15 (0.381) 20 (0.508) 40 (1.016)	– – –	– – –

¹ ASTM D 1000.

* Other custom colors available upon request.

² Scapa North America Test Method.

** Must be applied using constant tension brakes, applying tension to the tape itself and not the roll core.

OUTERWRAPS

RENWRAP Product #	Description	Colors	Total Thickness mils (mm)	Backing Thickness mils (mm)	Adhesive Thickness mils (mm)
355**	Machine applied polyethylene film, calendered with a butyl rubber adhesive.	White & Black	15 (0.381) 20 (0.508) 25 (0.635) 40 (1.016)	10 (0.254) 15 (0.381) 20 (0.508) 35 (0.889)	5 (0.127) 5 (0.127) 5 (0.127) 5 (0.127)
355-30**	Machine applied polyethylene film, calendered with a butyl rubber adhesive.	Gray*	30 (0.762)	25 (0.635)	5 (0.127)
356**	Machine applied polyethylene film, calendered with a butyl rubber adhesive.	White & Black	25 (0.635)	20 (0.508)	5 (0.127)
359 HT/HS**	Machine applied ESCR polyethylene film, calendered with a butyl rubber adhesive.	White	20 (0.508)	15 (0.381)	5 (0.127)
365**	Machine applied polyethylene film, calendered with a butyl rubber adhesive.	White, Black & Light Blue	20 (0.508) 25 (0.635) 30 (0.762)	15 (0.381) 20 (0.508) 25 (0.635)	5 (0.127) 5 (0.127) 5 (0.127)
366 LT**	Machine applied polyethylene film, calendered with a butyl rubber adhesive for low temperature in-service operating conditions.	Black	25 (0.635)	20 (0.508)	5 (0.127)

¹ ASTM D 1000.

* Other custom colors available upon request.

** Must be applied using constant tension brakes, applying tension to the tape itself and not the roll core.

Adhesion to Primed Steel ¹		Tensile Strength ¹		Elongation ¹	Dielectric Strength ¹	Dynamic Shear ²	Application
kg/cm width	lbs./inch width	kg/cm width	lbs./inch width	%	KV	Width kg/cm ² (psi)	
1.70	9.40	4.46	25	150	11	–	General pipeline utility tape for use on small diameter pipe joints, tees and ells.
1.90	10.90	4.46	25	150	13	–	
2.20	12.50	5.36	30	175	20	–	
3.04	17	7.14	40	250	21	–	Over the ditch or plant applied coating on pipelines. The product is also used on pre-fabricated bends.
3.04	17	7.14	40	250	21	–	
3.04	17	7.14	40	300	22	–	
3.04	17	7.14	40	300	23	–	
3.93	22	7.14	40	250	21	3.57 (20)	Over the ditch or plant applied coating on pipelines. The product is also used on pre-fabricated bends.
3.93	22	7.14	40	300	22	3.57 (20)	
4.64	26	8.04	45	275	22	3.57 (20)	High temperature/high shear anti-corrosion pipeline coating for over the ditch or plant applied applications.
2.50	14	2.50	14	200	14	–	Pipeline joint/handwrap for wrapping field joints, fittings ells and tees.
2.50	14	2.50	14	225	17	–	
2.50	14	2.50	14	250	19	–	
4.11	23	4.11	23	250	26	–	
2.20	12.50	3.60	20	250	19	–	Used for applications where a high bond at the overlap is required in pipeline joint/handwrap for field joints, fittings ells and tees.
2.50	14	3.60	20	250	19	–	
4.11	23	4.11	23	250	26	–	
Exceeds tensile strength		–	–	>500	–	–	Conforming and filling voids around irregular shapes such as tees, ells, valves and couplings.
–	–	5.36	30	150	–	–	Outerwrap and rock shield. The product is designed for use where a bond to anti-corrosion coating is not required.
–	–	6.25	35	200	–	–	
–	–	7.14	40	200	–	–	

Adhesion to Backing ¹		Tensile Strength ¹		Elongation ¹	Application
kg/cm width	lbs./inch width	kg/cm width	lbs./inch width	%	
0.56	3.125	5.36	30	250	Outerwrap and rock shield. The product is designed to protect RENWRAP innerwrap from mechanical damage during lowering-in, backfilling and in-service of pipelines.
0.56	3.125	7.14	40	300	
0.56	3.125	7.14	40	300	
0.56	3.125	8.04	45	350	
0.56	3.125	8.04	45	350	Outerwrap for RENCOAT [®] 50 and RENCOAT 80 plant applied coating systems.
0.56	3.125	8.04	45	350	Reconditioning projects to protect RENWRAP innerwrap from mechanical damage during lowering-in, backfilling and in-service of pipelines.
0.73	4.06	6.25	35	400	Protective outerwrap for high temperature/high shear anti-corrosion pipeline coatings.
0.56	3.125	7.14	40	400	Pipeline outerwrap specifically designed for use in plant coating operations where controlled applications exist.
0.56	3.125	8.04	45	400	
0.56	3.125	9.82	55	400	
0.56	3.125	8.93	50	400	Pipeline outerwrap specifically designed for use in plant coating operations where controlled applications exist.

PRIMERS

RENWRAP Product # ³	Description	Color	Base Adhesive System	Solvent System	Total Solids %	Viscosity	Flash Point
319 ***	Recommended for machine application to new or smooth pipe services. Promotes high bond to RENWRAP pipeline coatings.	Black	Synthetic rubber and resins	Heptane/ Toluene	19	Thin Syrup	-12C (+10F)
327 ***	Recommended for use on all hand-brush applications with RENWRAP pipeline coatings. Can also be used in machine applications to rough, reconditioned surfaces where a higher solids content is needed.	Black	Synthetic rubber and resins	VM&P Naphtha/ Toluene	27	Medium Syrup	-4C (+40F)
327 Aerosol***	Aerosol primer recommended for use on all RENWRAP pipeline coatings. Can also be used in machine applications to rough, reconditioned surfaces where a higher solids content is needed.	Black	Synthetic rubber and resins	VM&P Naphtha/ Toluene	27	Medium Syrup	-4C (+40F)
328	Recommended for use with RENWRAP pipeline coatings. Used for non-flammable applications where extreme safety precautions are observed.	Black	Synthetic rubber and resins	Trichloroethylene	11	Thin Syrup	Non-flammable

³ Also available in high temperature/high shear, available in 1, 5 and 55 gallon units.

*** Flammable mixtures. See technical data sheet for further information.



North American Headquarters
111 Great Pond Drive
Windsor, CT 06095
(860) 688-8000
FAX (860) 688-7000

800-653-5249
www.scapana-pipe.com
appsupport@scapana-pipe.com