

## Complementary/ lithographic products

### Scapa's complementary and lithographic products meet all your print finishing needs

#### Scapa offers a full range of complementary tapes for plate proofing and mounting.

Like all our **Exafit**<sup>®</sup> double-sided foam and filmic tapes dedicated to the mounting of clichés, Scapa's Complementary tapes are precision engineered using the latest advances in materials and adhesive technology.

At every stage in plate mounting, from proofing to final edge sealing applications, Scapa offers a suitable product for the application.

The Scapa range of complementary products includes:

- Single sided tapes for edge sealing and wrapping of rollers that come into contact with inks or adhesives
- Double-sided tapes for edge fixing

Our products use high performance adhesive formulations to feature:

- Excellent resistance to inks, solvents and in most cases, to heat
- Quick stick and high tack properties



#### Scapa also offers a full range of tapes for all your lithographic needs, which offer you many benefits:

- Excellent adhesion on films/plates and to other plastic substrates
- Elimination of edge copying during processing to ensure right-first-time results, saving you time and money
- One product for effective performance on both film and plastic sheeting
- Masking and mounting tapes for both negative and positive films/plates
- PVC tapes for high humidity
- High visibility light-transparent tapes

Scapa tapes can also be tailored to meet the most challenging needs of our individual customer needs. Contact Scapa to find your perfect solution.



**Complementary / Lithographic** solutions

# Scapa Complementary / Lithographic solutions

Product	Thickness (μ)	Carrier / Adhesive	Peel adhesion* (N/25mm)	Comments
<b>Lithographic</b>				
1140	45	Cellulose / Rubber	5.5	Blue for ease of identification. For use on positive films.
1129	45	Cellulose / Rubber	5.5	Red cellulose for negative films.
1250	45	Clear polypropylene / Acrylic	5	Holding positive and negative films in place.
1919	54	Frosted matt acetate film / Acrylic	6.5	Easy unwind properties. Good adhesion, but removes cleanly. Hand tearable. For securing proofing paper to mounters and proofers.
2258	57	Red PVC / Rubber	5	PVC for negative films, especially for humid conditions.
<b>Edge Sealing</b>				
D160	110	PET / Acrylic	15	Double-sided tape for bonding on difficult substrates, such as composite sleeves.
4400	100	u-PVC / Rubber	13	General purposes double-sided bonding tape. Provides high tack and clean removability after use.
4403	240	u-PVC / Acrylic	27.5	Double sided tape for bonding on difficult substrates, such as composite sleeves.
336	110	50μ Aluminium / Acrylic	15	Single sided tape with excellent heat and solvent resistance. Aluminum carrier ensures a barrier against inks and solvents.
1695	45	Aluminised PET / Acrylic	6.5	Single sided tape with excellent heat and solvent resistance. Will not leave any residue upon removal.
2721	160	Soft PVC / Rubber	5	Single sided bonding tape with an aggressive adhesive system and easy transversal tearability.
3120	300	PE coated cloth / Rubber	10	Single-sided tape with excellent heat resistance. Easy unwind and tear properties.
<b>Rolls Coveting</b>				
2420	600	Embossed silicone rubber coated cloth / Rubber	5.5	Single-sided tape with high adhesion, high shear resistance and high continuous temperature resistance. Provides anti-slip or anti-adherent surface. Removes cleanly and easily.
2421	400	Smooth silicone rubber coated cloth / Rubber	5.5	Single-sided tape with high adhesion, high shear resistance and high continuous temperature resistance. Provides anti-slip and anti-adherent surface. Removes cleanly and easily.

\*Peel adhesion is measured at 180° to the surface on the stainless steel

For further information, please contact Scapa European Customer Care in your preferred language:

**English**  
Tel: +44 (0) 161 301 7409  
Fax: +44 (0) 161 301 7445

**Deutsch**  
Tel: +49 (0) 621 470 91-0  
Fax: +49 (0) 621 470 91-80

**Español**  
Tel: +34 93 652 99 40  
Fax: +34 93 620 51 27

**Français**  
Tel: +33 (0) 475 44 80 00  
Fax: +33 (0) 475 44 80 53

**Italiano**  
Tel: +39 0161 867 400  
Fax: +39 0161 860 329

[www.scapaeurope.com](http://www.scapaeurope.com)

