



Single Sided Self-Adhesive Foam Products

For water, air, dust and draught sealing, gap filling, cushioning and protecting

As Europe's leading manufacturer of self-adhesive foam material, Scapa have specialist expertise in manufacturing and developing foam products for bonding, sealing, cushioning, protection, mounting and fixing applications.

The Scapa single sided foam range provides solutions to practically every industry for applications such as water, air, dust and draught sealing, gap-filling, cushioning and protecting. The products are economical, easy and quick to apply, clean to use, adaptable, versatile and consistent.

Scapa can supply the foam tape range in a variety of formats including logs, rolls, bobbins, pads, discs, sheets, washers, gaskets or other die cut shapes to suit every application requirement.

The products included in this brochure are the core, standard product range. Other colours, thickness' and product structures are available upon request.

Product Thickness' (mm)

	0.8	1.5	2	2.5	3	4	4.5	5	6	7.5	9	10	10.5	12	15
3099					■		■		■		■			■	
3124						■		■							
3154					■		■		■					■	
3204					■		■								
3209					■		■		■						
3239				■											
3257		■			■		■		■						
3259		■			■		■		■	■	■		■	■	■
3492					■		■								
3507	■	■		■	■		■		■						
3509	■	■			■		■		■						
3594					■		■								
3824			■ (40)		■	■ (20)		■ (15)	■						
3829			■ (40)		■	■ (20)		■ (15)	■			■			
3909			■ (8)		■ (6)			■ (4)				■ (4)			

Standard Roll Length (m)

Thickness (mm)	0.8	1.5	2	2.5	3	4	4.5	5	6	7.5	9	10	10.5	12	15
Length (m)	60	50	30	30	25	15	15	12	12	10	8	8	7	6	5

Tolerances

Thickness

PVC/PU foam ± 10% (0.8mm:-15% to +20%)

Foam width

Below 25mm ±0.5mm

Scapa European contacts

Scapa is a leading global manufacturer and supplier of technical adhesive tape solutions and polymer-based products to virtually every industry. With offices and manufacturing sites across the world, Scapa offers specialist applications expertise and products from stock or as custom design, either directly or through a network of Select Partners and Authorised Agents.

For more information please contact European Customer Support in your preferred language

English

Tel: +44 (0) 161 301 7400

Fax: +44 (0) 161 301 7445

Français

Tel: +33 (0) 475 44 80 00

Fax: +33 (0) 475 44 80 53

Italiano

Tel: +39 0161 867400

Fax: +39 0161 860329

Deutsch

Tel: +49 (0) 621 4 70 91-0

Fax: +49 (0) 621 4 70 91-80

Español

Tel: +34 93 652 99 40

Fax: +34 93 630 5127



Single Sided Self-Adhesive Foam Products

For water, air, dust and draught sealing, gap filling, cushioning and protecting

Product	Colour	Compression to Effect Seal %	Seal Type	Shore Hardness '00'	Force to Compress N/cm ²	Compression deflection N/cm ²	Service Temperature °C	Description / Applications	
Soft Range									
3099	Black	30	Water	25	1.5	1.0	-30 to +70	<ul style="list-style-type: none"> UV resistant PVC foam Very soft with easy compression Ideal for irregular or uneven surfaces Suitable for anti-rattle, anti-vibration applications, producing watertight seals and cushioning 	<input type="checkbox"/>
3124	White	50	Air & Dust	N/A	1.1	0.8	-30 to +70	<ul style="list-style-type: none"> UV resistant PVC foam Very soft with easy compression Fixed polyester liner for clean make or break seal Used in applications requiring a dust seal 	<input type="checkbox"/>
3204	White	30	Water	30	2.6	1.6	-30 to +70	<ul style="list-style-type: none"> Soft UV resistant PVC foam Soft multi-purpose foam seal Approved to DIN 4102 Pt1 B2 Used for lightweight watertight sealing 	<input type="checkbox"/>
3209	Black								
Medium Range									
3154	White	50	Air & Dust	25	1.7	1.1	-30 to +70	<ul style="list-style-type: none"> Medium hardness UV resistant PVC foam Excellent recovery properties Good resilience Used in sealing and cushioning applications 	<input type="checkbox"/>
3239	Black	30	Weather	N/A	4.4	3.5	-30 to +70	<ul style="list-style-type: none"> Multi-purpose UV resistant PVC foam seal Used in applications where a make or break seal is required to create a weatherproof seal 	<input type="checkbox"/>
3257	Grey	30	Water	35	2.8	2.4	-30 to +70	<ul style="list-style-type: none"> Medium hardness UV resistant PVC foam Similar properties to Neoprene Approved to DIN 4102 Pt1 B2 Used as multi-purpose foam seal, as metal separator, and as anti-slip pad 	<input type="checkbox"/>
3259	Black								
Hard Range									
3492	Green	30	Water	65	10	7.0	-30 to +70	<ul style="list-style-type: none"> Very hard UV resistant PVC foam Designed for glass protection pads and as temporary compression seals Will leave no adhesive residue on removal 	<input type="checkbox"/>
3507	Grey	30	Water	50	4.8	4.0	-30 to +70	<ul style="list-style-type: none"> Hard UV resistant PVC foam Designed for high load bearing applications Ideal for vibration damping and cushioning 	<input type="checkbox"/>
3509	Black								
3594	White	30	Water	55	5.5	4.0	-30 to +70	<ul style="list-style-type: none"> Flame retardant UV resistant PVC foam Multi-purpose foam seal Ideal for all types of seal, especially where a high degree of flame retardancy is required Achieves class 1 to BS476 part 7 UK Building Regulations, Achieves Class O 	<input type="checkbox"/>
3824	White	20	Weather	55	3.0	2.5	-30 to +80	<ul style="list-style-type: none"> PE foam with fixed LDPE liner Approved to DIN 4102 Part B3 3824 approved by WRAS (5470) Ideal for air and weathertight seals, as a corrosion inhibitor, and anti slip pads Rubber resin adhesive 	<input type="checkbox"/>
3829	Black								
Expanding Foam Products									
3909	Black	80	Water	N/A	0.5	N/A	-30 to +80	<ul style="list-style-type: none"> Expandable PU foam Approved to DIN 4102 Pt 1 B1 rating Expands to 5 times original thickness Ideal for gap filling and air sealing between uneven surfaces 	<input type="checkbox"/>

All foam tapes have acrylic adhesive unless otherwise stated. Waterseals also act as air/dust seals. Higher service temperature products are also available.

Our technical advice whether given verbally, in writing, by way of trials, or in any other manner is to be regarded as an expression of opinion only. Although such advice is given in good faith it shall not be regarded as the basis of or as a representation or statement of fact and this applies also where propriety or protective rights of third parties are involved. Since we have no control over the use to which you intend to put our products, our advice tendered does not release you from your obligation to test products supplied by us as to their suitability and application. Whilst our products will be of consistent quality their application use and processing must therefore be entirely your own responsibility. Any liability arising in respect of our products will be strictly limited to the value of such products as at the time of delivery and shall not extend to any consequential loss whatsoever and howsoever arising. Freedom from Patent Rights must not be assumed. This document does not form part of any contract with a customer.